




COMPUTIMER™

PROGRAMMING INSTRUCTIONS


1. SETTING TOKENS TO START

- A. Press buttons "S2" then "S5" both red lights will be lit.
- B. Press "S6" button to increase the number of tokens to start. Press "S7" to decrease the number of tokens to start.



2. SETTING TIME per TOKEN

- A. Press buttons "S2" then "S4" both red lights will be lit.
- B. Press "S6" button to increase the amount of time per token in 5 second increments. Press "S7" to decrease the amount of time per token.




COMPUTIMER™

page 2

PROGRAMMING INSTRUCTIONS


3. SETTING COINS TO START

- A. Press buttons "S3" then "S5" both red lights will be lit.
- B. Press "S6" button to increase the number of coins to start. Press "S7" to decrease the number of coins to start.



4. SETTING TIME per COIN

- A. Press buttons "S3" then "S4" both red lights will be lit.
- B. Press "S6" button to increase the amount of time per coin in 5 second increments. Press "S7" to decrease the amount of time per coin.




COMPUTIMER™

page 3

PROGRAMMING INSTRUCTIONS


5. SETTING GRACE TIME

- A. Hold button "S4", press "S5" then release both.
Display will read "on" or "off".
- B. Press "S6" button to turn Grace Time "on".
- C. Press "S7" button to turn Grace Time "off".



6. SETTING ALERT to Pulse/ No Pulse

- A. Press buttons "S6", press "S7" then release both.
P (pulse) or nP (no pulse) will be displayed.
- B. Press "S7" button for Pulse.
- C. Press "S6" button for No Pulse.



COMPUTIMER™


page 4

PROGRAMMING INSTRUCTIONS

7. DISPLAY TOKEN COUNT

- A. Press button "S2".
Token count is displayed.
- B. Press button "S1" to reset token count.


EXAMPLE:
24 Tokens



8. DISPLAY COIN COUNT

- A. Press button "S3".
Coin count is displayed.
- B. Press button "S1" to reset coin count.

EXAMPLE:
96 Coins




COMPUTIMER™

PROGRAMMING INSTRUCTIONS

9. DISPLAY CAR COUNT

- A. Press and Hold button "S2", press "S3", then release both. Car Count will be displayed
- B. Press button "S1" to reset car count.

EXAMPLE:
24 Cars



WIRING CONNECTIONS

